





Ceiling mount bracket for Snapit™ vandal dome cameras



WHAT'S IN THE BOX

Camera Mounting Screws		4	Quick Setup Guide		1
Screws and Plastic Anchors		4	Mounting Template		1

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



INSTALLATION

- 1 Using the mounting template or the mounting bracket itself, mark and drill the necessary holes on the mounting surface.
- 2 Secure the mounting bracket to the mounting surface using the screws and anchors included.
- 3 To mount the camera to the mounting accessory, remove the dome from the camera base using the wrench included with the camera. Remove the camera base from the junction box by loosening the screws at the base of the camera.

NOTE: Do not touch the lens when handling the camera.

- 4 Secure the camera's junction box to the mounting bracket using the included camera mounting screws.
- 5 Pass wires through the mounting bracket and make all necessary connections with the camera. Use the cable holder, at the base of the junction box, to manage the camera's cables as needed.
- 6 Connect the camera to the junction box, adjust the camera's position and angle and complete the installation by placing the dome cover on the camera. Secure the dome cover to the camera's junction box using the screws included with the camera. See the camera's QSG for more information.

